VALVE-MOUNTED WHEEL UNIT SENSOR

COMMERCIAL VEHICLE TPMS COMPONENTS

The wheel unit sensors are mounted to the valve on the inside of the rim. They are mounted with an adjustable angle, making them suitable for almost any rim configuration.



SPECIFICATIONS

Features

TIRE PRESSURE MONITORING:

- General Safety Regulation (GSR) compliant (Europe)
- Tire pressure by wheel location
- Temperature compensated pressure sensing
- High pressure / low pressure warning
- High temperature warning
- Spare tire monitoring

AUTO-LOCATION:

• Automatic location of all tire sensors to correct wheel positions, eliminating need for manual programming of tire sensors.

Sensata

Technologies

TIRE FILL ASSIST:

- Allows vehicle operator to fill tire to exact, temperature compensated, pressure rating.
- Removes the need for a separate pressure gauge.

TIRE LOCK WARNING:

- · Warning when a tire does not rotate
- Can be combined with a lowered position of a tag / lift axle

TIRE BURST WARNING:

- Detects fast pressure drop caused by tire blow out
- Sends a warning signal, including specific tire location
- Allows for vehicle reaction control upon a tire burst event

| Sample Rate | Temperature | Every 15 sec |
|---------------|-------------------|---|
| | Pressure | Every 15 sec (<200ms at Tire Burst) |
| | Motion | Every 15 sec |
| Transmission | Drive Mode | Every 15 sec |
| | Event Mode | <200ms at Tire Burst |
| | Stationary Mode | Every 120 sec |
| Functionality | Frequency | 433MHz (315 MHz Japan) worldwide approvals |
| | Temp Range | -40°C to +125°C |
| | Pressure Range | 0 to 14 Bar relative |
| | Temp Accuracy | +/- 2 °C |
| | Pressure Accuracy | +/- 200mBar within -40°C to 125°C. |
| | Battery Life | 5 to 7 years based on supported feature set |
| | Mounting | Variable mounting angle to 100° |
| | | |
| | | Tire Pressure |
| | | Tire Temperature |
| | | Battery Warnings |
| Eurotionality | | Temperature Compensation |
| Functionality | | Auto Learn |
| | | Tire Lock Warning |
| | | Tire Burst Warning |

Tire Fill Assist



Flexible Valve Angle

>100o adjustable valve angle accommodates diverse valve types



Mount valve to rim

Place sensor against rim and install M6 screw





Torque screw to complete installation





VMS CALIBRATION & PAIRING



Manual Learn

Overview: A manual learn system requires each tire sensor to be programed with a Low Frequency tool in order to pair the sensor with tire location and to the specific gateway.

Advantages: Lower overall system cost based on complexity and lower component count. **Disadvantages:** Requires purchased of low frequency tool to be used for servicing tires in the system.



Auto-locate

Overview: A auto-locate system uses Sensata patented wireless auto-location (WAL) and phase auto-location technology (PAL) to automatically locate and program tire location and pair to ECU. **Advantages:** No additional tool is required to program the tire sensor and location for tire service. **Disadvantages:** Requires additional External Receiver module to provide reliable WAL sensing.

Page 2

Sensata Technologies, Inc. ("Sensata") data sheets are solely intended to assist designers ("Buyers") who are developing systems that incorporate Sensata products (also referred to herein as "components"). Buyer understands and agrees that Buyer remains responsible for using its independent analysis, evaluation and judgment in designing Buyer's systems and products. Sensata data sheets have been created using standard laboratory conditions and engineering practices. Sensata has not conducted any testing other than that specifically described in the published documentation for a particular data sheet. Sensata may make corrections, enhancements, improvements and other changes to its data sheets or components without notice.

Buyers are authorized to use Sensata data sheets with the Sensata component(s) identified in each particular data sheet. HOWEVER, NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER SENSATA INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY THIRD PARTY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT, IS GRANTED HEREIN. SENSATA DATA SHEETS ARE PROVIDED "AS IS". SENSATA MAKES NO WARRANTIES OR REPRESENTATIONS WITH REGARD TO THE DATA SHEETS OR USE OF THE DATA SHEETS, EXPRESS, IMPLIED OR STATUTORY, INCLUDING ACCURACY OR COMPLETENESS. SENSATA DISCLAIMS ANY WARRANTY OF TITLE AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, QUIET ENJOYMENT, QUIET POSSESSION, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS WITH REGARD TO SENSATA DATA SHEETS.

All products are sold subject to Sensata's terms and conditions of sale supplied at www.sensata.com SENSATA ASSUMES NO LIABILITY FOR APPLICATIONS ASSISTANCE OR THE DESIGN OF BUYERS' PRODUCTS. BUYER ACKNOWLEDGES AND AGREES THAT IT IS SOLELY RESPONSIBLE FOR COMPLIANCE WITH ALL LEGAL, REGULATORY AND SAFETY-RELATED REQUIREMENTS CONCERNING ITS PRODUCTS, AND ANY USE OF SENSATA COMPONENTS IN ITS APPLICATIONS, NOTWITHSTANDING ANY APPLICATIONS-RELATED INFORMATION OR SUPPORT THAT MAY BE PROVIDED BY SENSATA.

Mailing Address: Sensata Technologies, Inc., 529 Pleasant Street, Attleboro, MA 02703, USA.

CONTACT US Regional head offices: United States of America Sensata Technologies Attleboro, MA Phone: 508-236-3800 E-mail: support@sensata.com Netherland Sensata Technologies Holland ΒV Hengelo Phone: +31 74 357 8000 E-mail: support@sensata.com Sensata Technologies China Co., Ltd. Shanghai Phone: +8621 2306 1500 E-mail:support@sensata.com

www.sensata.com